
USER MANUAL

Intelligent Solar Light(YL series)



FAQ

Why Intelligent Solar light (YL series) do not light on?

1.Make sure waterproof connector is connected.

2.Activating charge when first installation. Connect solar panel to light body and make sure solar panel face to sunlight directly at least 5s, then check is it light on at night.


If above information still cann !'solve your problem, pis contact sales team directly, we will happy to serve you all the time.

Does it need clean surface of panel?


Yes, it is needed to clean surface regularly according to the gravity of the dust in local city

Does the lamp light on automatically?

Yes, it will light on automatically at darkness no matter which mode except "OFF".




Power function



Battery indicator

Working mode



DEMO: No matter day or night,light "on" for 1 minute. Only for test use.

OFF: Light" off" ,no matter day or night

L: At night,100%-3hrs,50%-2hrs,20%-dawn

T: At night,100%-3hrs,50%-3hrs,30%-2hrs


M: At night,100%-3hrs,50%-3hrs

U: At night,100%-3hrs,50%-3hrs(Highlight mode)

Remark

1. 6 working modes option via remote control, default mode is L.
2. U Highlight mode: Increase 30% on the original basis, mean 3H-130%, 3H-80%

Assembling steps of YL-30P



Assembling steps of YL-60P

